

Ruhsitzstrasse 22 (Level 1 - 3 ost)

When there are too many electrical appliances running at the same time (e.g. the heater in the bedroom behind the kitchen and the microwave) what may happen is a black out. Should this happen please move the grey switch from 0 to the symbol I. As in the photo below. The power will then be restored to the apartment.



If that fails. Then go to the fuse box in your apartment to see if all the flip switches are all turned up. If you see a switch that is not flipped up, please do so and the electricity will be turned back on.



If there is no fuse box in the apartment then you will find the fuse box in the basement of the house close to the washing machine rooms. It looks like the photo below.

It is possible that a fuse has blown. Check which fuse belongs to your apartment. Each fuse is for a certain function in the apartment e.g.. if the light has blown then check the fuse, which says light. Unscrew the fuse out from its position and replace it with a new fuse. There should be a couple of new fuses close at hand. The electricity will then be stored back to your apartment. If all fails then please send an email to the housing office (housing@unisg.ch).